

B022SP : Bottle roller

STANDARD : EN 12697-11

To determine the affinity between aggregate and bitumen, expressed by visual registration of the degree of bitumen coverage on uncompacted bitumen-coated mineral aggregate particles after influence of mechanical stirring action in the presence of water. Rotation speed adjustable from 0 up to 85 rpm.

The machine can roll up to 3 bottles at the same time.

Supplied complete with timer range 0 - 99 hours to fully perform the test cycle.

- **Power supply:** 230V 50-60Hz 1ph
- **Dimensions:** 385x295x160 mm
- **Weight:** 10 kg approx.

Accessory:

S132-01 Graduated impurities test bottles



B022SP

BAG-MacBen BV
Oostjachtpark 12,
B-9100 Sint-Niklaas

T: +32 3 771 48 04 info@macben.eu
www.macben.eu

BAG-MacBen
Smederijstraat 2,
NL-4814 DB Breda

T: +31 765 30 23 73 sales@macben.eu
www.macben.eu